


Access control and video security ideally linked together. AMAG Symmetry and Geutebrück G-Core




With the Geutebrueck network interface G-Link/AMAGSymmetry you can easily link the AMAG Symmetry Acces Control and Security Management System with our G-Core video management software.

The data exchange between the systems is bidirectional. Access control data, such as opening or closing doors, starting the automatic recording of the assigned camera players as well as the display of live images.

Conversely, you control the opening or locking of doors via the Geutebrueck system.

The status of the doors (open, closed) can be graphically displayed and remotely controlled in G-SIM maps.

- Convenient interface to AMAG Symmetry via the Geutebrueck Integration Server G-Link for bidirectional data exchange with G-Core and other third-party systems.
- Reliable visualization of access controls with the corresponding video images.
- Event-driven forwarding of videos to mobile devices is possible.
- Intrusions, card misuse or vandalism: nothing goes undetected.
- Control functions in G-Core for opening or unlocking selectable doors.
- Map-based operation with the Geutebrueck Security Information Management System G-SIM.
- Display of faults in the map (G-SIM) with automatic connection of the assigned video camera.



System overview: G-Link/AMAGSymmetry

Recommended uses and applications

G-Link/AMAGSymmetry is used to integrate the AMAG TECHNOLOGY's access and security management system. Especially user-friendly with the graphical user interface in G-SIM.

www.geutebrueck.com



Technical data

G-Link/AMAGSymmetry-SI-EN 19.03.2018

Designation	Function examples
Event messages from AMAG Symmetry:	Access information: Status door open/closed Invalid Batch (no access) Door Forced Open Door Held Open Monitoring Inputs/Outputs Event Mapping: Every AMAG Symmetry message can trigger configurable G-Core actions. Camera activation, image storage, control of PTZ cameras, automatic forwarding of alarm images.
G-Core actions control AMAG Symmetry:	Control data for opening and closing a door: Lock door Unlock door
Requirements:	G-Link server software (dongle) Order No. 3.06530 Software option G-Link/activation Order No. 8.34148 Software option G-Link/G-Core Order No. 8.34172 G-Link server
Required licenses:	Software option G-Link/AMAGSymmetry Order No. 8.34184

Technical changes and delivery options reserved.

GEUTEBRÜCK GmbH

Im Nassen 7-9 · D-53578 Windhagen · Tel. +49 (0)2645 137-0 · Fax-999 · E-mail: info@geutebrueck.com · Web: www.geutebrueck.com